


Mesh Transmitter

[View table of content.](#) [View table of content.](#)

How this block appears in a Simulink model?

[300](#)

What can be configured?



Configuration Parameter	Selectable Option/Value	Description
Number of Receivers		Enter the number of nodes at the receiving end.

When to use this block?

This block can be used to data from one node to other nodes in a mesh network.

Previous : [Mesh Setup](#)

Next : [Mesh Receiver](#)

Files

File Name	Size	Date	Author
appearance_send.PNG	7.09 KB	20 Oct 2020	Vasitha Tilakumara (රාච්චි)
mask_send.PNG	10.5 KB	20 Oct 2020	Vasitha Tilakumara (රාච්චි)